## Frequently Asked Questions HERMITAGE BATH

For product support, please email: steven@hermitagebath.com

# 1. Is the surface of the glass resistant to spots and stains due to spot guard treatment?

The glass surface features an easy-clean coating, which prevents liquid from adhering to it, thereby achieving anti-stain performance.

**Tip:** Screen-printed glass does not come with an easy-clean coating. This applies to the following models: HB7151C-7660SV, HB7151C-7660BL, HBSD7151CB-7660MB, HB7051C-7660BL, HB7051C-7660SV, HB7051C-7660BN, HB7051C-7660G, HBSS1010A-3472MB, HBSS1010B-3472MB, HBSS1010C-3472MB

#### 2. Is this compatible with fiberglass bathtub walls?

Yes, our products are compatible with most of the bathtubs available on the market.

#### 3. Are the 2 doors sliding or just 1?

The 2 doors are sliding.

**Tip:** Models HBS-7051BN, HBS-7051MB, HBS-7051SV, H7051-6060BN, H7051-6060MB, and H7051-6060SV are single sliding doors. Models HBSS1010A-3472MB, HBSS1010B-3472MB are shower panels.

#### 4. Is water leakage an issue with this door?

No one has said this problem yet.

### 5. Are there PFAs added to this product?

Although this product does not contain PFA, it offers excellent isolation effectiveness, making it a highly cost-effective choice.

## 6. Does the tub and shower doors come frosted glass?

Our bathtubs and shower doors are made from transparent tempered glass, not frosted glass.

## 7. Do you offer installation service, and what's the cost?

We sincerely apologize, but we do not offer on-site installation services.

## 8. Is this easy to DIY?

It's easy if you have extensive cutting experience, otherwise we recommend hiring a professional.

## 9. What is the most critical step during installation?

Ensuring the frame/track is perfectly level and plumb. This is the foundation of the entire installation. Even a slight misalignment can cause improper door operation, accelerated wear on rollers, or poor sealing.

#### 10. What preparations are needed before installation?

Before installation, please ensure:

- Floor & wall surfaces are fully completed: Tiles, flooring, and the bathtub must be installed and fully cured.
- Surfaces are level and plumb: Use a spirit level and plumb line to check. Uneven surfaces may cause installation issues, poor sealing, or even glass stress fractures.
- Sufficient clearance is available: Ensure there is enough space for the door to open smoothly without hitting obstacles like toilets or vanities.

#### 11. Why doesn't the door close properly or feel shaky after installation?

- Poor sealing: Often caused by an unlevel frame, preventing magnets or seals from engaging correctly. Debris in the track may also be the culprit.
- Shakiness: Loose mounting screws or insufficient wall stability can cause movement. Check all connection points for tightness.